

# 1. Example : P80 Factory rails



2.

← Rear



This point may require removal

3.

← Rear



When complete, connector side rail should look like this  
May require fine tuning

All modifications should be performed by a licensed gunsmith.  
By visiting this link and/or attempting to make the required modifications you acknowledge that we are not responsible for damage, repair or injury.